

Static-dissipative Field Kit

GENERAL

The Wind Profiler Program Office (PPO) has asked that a kit, which contains anti-static work pad and other static-dissipative equipment, be left at each wind profiler site. After distribution of this maintenance note, the PPO will begin distributing the kits to NWS electronics technicians.

Use this kit whenever you need to work on any static-sensitive equipment on the wind profiler.

PROCEDURE

The kit should be at the profiler site within 30 working days of receipt. The PPO will send a return addressed postcard along with the field kits. Sign and date the postcard and return it to the PPO via U.S. Mail.

The static-dissipative field kit should be located at the wind profiler site and placed in the workbench or another easily accessible location.

EFFECT ON OTHER INSTRUCTIONS

None.



J. Michael St. Clair
Chief, Engineering Division